

Force-based movement enables the operator to change speed and direction. Forward speed can also be controlled using the foot pedal.

Target speed adjustment — set a target speed to match your exact needs.

Target speed selection — allows you to change between three target speeds.

#### 4 driving modes to suit your driving style:

**Auto Mode.** Once the desired target speed is achieved, Auto Command™ will match the engine and transmission to maintain it.

**Cruise Mode.** Cruise Mode allows the operator to achieve a set target speed at the touch of a button, and to maintain the speed for economy and productivity.

**Manual Mode.** Allows the operator to manually set the required engine and forward speed, independently of each other.

**PTO Mode.** As soon as the PTO is engaged, Auto Command™ will operate to achieve a constant engine speed.

